


WQ Series		
Part	Kit (installed along width)	Kit (Installed along length)
WQ-35	DR-05	DR-08
WQ-38	DR-07	DR-16
WQ-42	DR-07	DR-24
WQ-44	DR-15	DR-25
WQ-46	DR-17	DR-17
WQ-48	DR-17	DR-13
WQ-50	DR-17	DR-23
WQ-51	DR-17	DR-23
WQ-55	DR-13	DR-13
WQ-57	DR-18	DR-20
WQ-59	DR-18	DR-20
WQ-62	DR-29	DR-31
WQ-64	DR-20	DR-36
WQ-66	DR-20	DR-20
WQ-68	DR-20	DR-36
WQ-70	DR-31	DR-31
WQ-73	DR-31	DR-40
WQ-76	DR-36	DR-45
WQ-77	DR-36	DR-55
WQ-80	DR-45	DR-55
WQ-81	DR-45	DR-65
WQ-83	DR-55	DR-75

WH Series		
Part	Kit (installed along width)	Kit (Installed along length)
WH-02	N/A	DR-10
WH-04	N/A	DR-16
WH-06	N/A	DR-12
WH-08	N/A	DR-14
WH-10	DR-16	DR-16
WH-14	DR-12	DR-12
WH-16	DR-18	DR-20
WH-18	DR-18	DR-20
WH-22	DR-21	DR-32
WH-32	DR-36	DR-45

ZH/ZQ Series		
Part	Kit (installed along width)	Kit (Installed along length)
ZH/ZQ 040404	DR-50	DR-50
ZH/ZQ 060404	DR-50	DR-52
ZH/ZQ 060604	DR-52	DR-52
ZH/ZQ 080604	DR-52	DR-54
ZH/ZQ 080804	DR-54	DR-54
ZH/ZQ 100802	DR-54	DR-56
ZH/ZQ 100804	DR-54	DR-56
ZH/ZQ 100806	DR-54	DR-56
ZH/ZQ 101006	DR-56	DR-56
ZH/ZQ 121004	DR-56	DR-58
ZH/ZQ 121006	DR-56	DR-58
ZH/ZQ 121206	DR-58	DR-58
ZH/ZQ 141206	DR-58	DR-60
ZH/ZQ 141406	DR-60	DR-60
ZH/ZQ 161407	DR-60	DR-62

HP Series		
Part	Kit (installed along width)	Kit (Installed along length)
HP-050403	DR-51	DR-50
HP-060504	DR-52	DR-51
HP-070504	DR-53	DR-51
HP-100604	DR-52	DR-56



Navigation Key	
Series	Page
WQ	Pg 1
WH	Pg 1
ZH/ZQ	Pg 1
HP	Pg 1
ML	Pg 2
SK	Pg 2
SG	Pg 2

*Length runs parallel to hinge

*Width runs perpendicular to hinge

SK Series		
Part	Kit (installed along width)	Kit (Installed along length)
SK-11	N/A	N/A
SK-12	DR-04	DR-06
SK-13	DR-03	DR-03
SK-14	DR-09	DR-09
SK-15	DR-03	DR-09
SK-16	DR-09	DR-09
SK-17	DR-03	DR-37
SK-18	DR-09	DR-37
SK-19	DR-37	DR-37
SK-20	DR-37	DR-42
SK-21	DR-37	DR-42
SK-22	DR-42	DR-47
SK-23	DR-37	DR-42
SK-24	DR-37	DR-42
SK-25	DR-04	DR-06
SK-26	DR-03	DR-09
SK-27	DR-03	DR-37
SK-28	DR-37	DR-37
SK-29	DR-09	DR-37
SK-30	DR-42	DR-47

SG Series			
Part	Kit (installed along width)	Kit (Installed along length)	Kit (Installed along short width)
SG-10	N/A	DR-06	N/A
SG-11	DR-06	DR-11	N/A
SG-12	DR-11	DR-11	N/A
SG-13	DR-11	DR-37	N/A
SG-14	DR-38	DR-39	N/A
SG-15	DR-37	DR-42	DR-09
SG-16	DR-43	DR-44	DR-46
SG-17	N/A	DR-06	N/A
SG-18	DR-06	DR-11	N/A
SG-19	DR-11	DR-11	N/A
SG-20	DR-43	DR-44	DR-46
SG-21	DR-06	DR-37	N/A
SG-22	DR-11	DR-46	N/A

ML Series		
Part	Kit (installed along width)	Kit (Installed along length)
ML-92F	DR-27	DR-26

